

JAGUAR XK8





MAINTENANCE SCHEDULES.

CONTENTS PAGE	PAGE		
Corrosion (Perforation) Inspection	3		
Maintenance	3		
Service Intervals	4		
Maintenance Schedules	5		

FOREWORD



HER MAJESTY QUEEN ELIZABETH II
MANUFACTURERS OF DAIMLER AND JAGUAR CARS
JAGUAR CARS LIMITED COVENTRY



HER MAJESTY QUEEN EUZABETH THE QUEEN MOTHER MANUFACTURERS OF DAIMLER AND JAGUAR CARS JAGUAR CARS LIMITED COVENTRY



BY APPOINTMENT TO HIS ROYAL HIGHNESS THE PRINCE OF WALES MANUFACTURERS OF DAIMLER AND JAGUAR CARS JAGUAR CARS LIMITED COVENTRY

JAGUAR CARS LIMITED through their Dealers, offer a Maintenance Service Scheme to cover systematic maintenance at the intervals prescribed for your vehicle. Should the vehicle cover a low annual mileage or distance, a high proportion of short journeys or operate in severe conditions, it may require more frequent servicing or particular attention to specific items. Jaguar Dealers will be pleased to supply you with any information regarding particular service requirements.

When ordering a maintenance service, you give authority to the Jaguar Dealer to carry out the operations shown in the schedules applicable to your vehicle, including the replacement of consumable items. Jaguar Dealers may recommend the need for replacement parts, additional service operations or any further work which may be necessary due to wear and tear. These will be carried out only with your prior agreement.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from the Service Division of Jaguar Cars Limited.

The information contained herein applies to a range of vehicles and not to a specific vehicle. For the specification of a particular vehicle, owners should consult their Jaguar Dealer.

MAINTENANCE SCHEDULES

CORROSION (PERFORATION) INSPECTION

The 6 year Corrosion (Perforation) Inspection must be carried out at 12 month intervals from the date that the vehicle is handed over to the first Owner. Ensure that the Jaguar Dealer dates and signs the inspection record which can be found in the 'Service Record and Warranty' Book.

Jaguar Centres of Excellence

In the event of the vehicle requiring body repairs due to accident damage, your Jaguar Dealer can ensure that the repairs are carried out by a Jaguar Centre of Excellence, using only Jaguar approved parts, materials and repair techniques. This will ensure that warranty cover will continue on the repaired body sections for the remaining period of the Corrosion (Perforation) Warranty.

MAINTENANCE

Regular maintenance by a franchised Jaguar Dealer, together with the exclusive use of Jaguar parts, is the key to economy, safety and reliability for your vehicle.

The Maintenance Schedules may be revised from time to time. Jaguar Dealers will be notified of revisions by Service Policy Letters or Technical Bulletins.

The Vehicle Care Handbook gives further details of the maintenance operations required. Some simple checks/adjustments, which you or any filling station can perform, are required weekly or before a long journey. These include attention to the following items:

- Engine oil level.
- Brake reservoir fluid level.
- Power assisted steering reservoir fluid level.
- Coolant level.
- Battery levels (where applicable).
- Windscreen washer reservoir.
- Tyre pressures, including spare tyre.
- Operation of all lights and warning systems.

MAINTENANCE SCHEDULES

SERVICE INTERVALS

Maintenance must be carried out at 16 000 kilometres (10,000 miles) or 12 monthly intervals from date of delivery, whichever comes first.

It may be necessary for you to give your Jaguar Dealer adequate notice when ordering a maintenance service so that the prescribed intervals are not exceeded.

Ensure that the Jaguar Dealer dates and signs the service record which can be found in the 'Service Record and Warranty' Book.

Severe Driving Conditions

When vehicles are used under severe driving conditions maintenance must be carried out at 6 monthly intervals.

Severe driving conditions include:

- Driving in dusty conditions.
- Driving on unmetalled road surfaces.
- Driving in countries with high ambient temperatures.
- Driving in severe cold weather.
- Driving in areas using road salt or other corrosive materials.

Tyres

It is important for your safety that you always use the correct type of tyre and maintain your tyre pressures in accordance with the recommendations given in the Vehicle Care Handbook.

Check your tyres at frequent intervals for general condition, pressure and uneven wear, especially if fast motoring is anticipated.

Hydraulic Brake Systems

In addition to the recommended inspection of all brake components, it is advisable as a precaution against the effects of wear and deterioration, to make a more searching inspection and renew parts as necessary.

Brake fluid should be changed completely every two years. Only use the recommended brake fluid.

The work detailed for the brake system requires a great deal of skill and should be entrusted to your Jaguar Dealer.

MAINTENANCE SCHEDULES ¬

MAINTENANCE SCHEDULES

	16 000 km 10,000 miles	32 000 km 20,000 miles	48 000 km 30,000 miles	64 000 km 40,000 miles	80 000 km 50,000 miles	96 000 km 60,000 miles
Renew engine oil, oil filter and sump washer.	Х	Х	х	Х	Х	Х
Visually check underbonnet/underbody for any fluid leaks.	Х	Х	Х	х	X	Х
Grease drive shaft universal joints.	Х	х	х	Х	Х	Х
Inspect brake pads for wear (disc condition on pad change).	Х	Х	х	х	х	Х

Renew brake fluid.	Every 2 years							
Renew coolant.	Every 4 years or 96 000 km (60,000 miles)							
Renew air cleaner element.			Х			X		
Renew fuel filter.						Х		
Renew spark plugs.			Х		 	X		
Renew spark plugs (leaded fuel markets only).	х		Х	<u> </u>	Х	ļ		
Check drive belt tension wear indicator – replace belt if necessary	X	Х	Х	Х	Х	х		
Renew drive belt.	160 000 km (100,000 miles)							



JJM 10 23 14/70